

BLOWER RESTRAINT INSTALLATION INSTRUCTIONS

Correct Strap Installation is critical to performance of the product.

The upper strap mount consists of an inner slot (closest to injector), and an outer slot which the strap is routed through. During this process keep strap loose to allow for adjustment.

After hardware is installed, begin by running the strap through the inside slot from the top of the mount and extending the strap to the outside of the mount (NOT OUTSIDE SLOT) from underside.

Route the strap through the outside slot from the top, and then slide the strap from the underside of the inside slot, as illustrated below.

Adjust to desired strap tension and pull end tight to complete mounting.

1. Hardware consists of a paddle, retainer pin, and wire with a hairpin. The paddle is mounted to the header stud with the larger end facing up. The paddle is not pre-drilled and will require a 3/8" hole at desired location. Longer stud may be required.
2. After the paddle is mounted, place sewn end of strap in line with the retainer pin mount.
3. Slide pin through retainer pin mount and strap.
4. To complete the process, slide hairpin and wire through hole on retainer pin

