


BLOWN ALKY

METERING VALVE



800-576-7661  
www.DragParts.com

FUEL TANK MUST BE VENTED

RETURN LINES MUST DISCHARGE AT OPPOSITE END OF TANK FROM MAIN FUEL LINE OR INLET OF FUEL PUMP

FUEL TANK